






2005 - 2009 Mustang




Connect according to the accompanying diagram

16-Pin Vehicle Connector


BACK VIEW (FRONT PLUGS IN, WIRES COME OUT OF THE BACK)

16 ● Black	15 ● Black	14	13	12 ● Tan	11	10 ● Pink	9 ● Red
8	7 ● Yellow	6	5	4	3 ● Green	2	1



Connecting the speedo out
See the installation manual's "Optional Features" section for more details.

2005 - 2009 Mustang Connector Locations



Quick 6 Backup Lamp Relay

for 2005 - 2009 Mustang
(Including GT500)

